

How to Prepare for a Lead Inspection


Cleaning Tips:

- Start high and clean the area as you work your way down to the floor.
- When you begin cleaning in each room, you should start at the furthest point from the exit.
- You will need to- vacuum, wash, vacuum.

Steps:

1. **Vacuum:** HEPA vacuum the entire area, start high and work your way down to the floor. Include window sills and wells. Vacuum the floor last.

2. **Wash:**



a. **Walls and Windows:** Should be detergent washed with water and cleaner.

- Use the 3-chamber method to wash:

1. Chamber #1: Water & detergent (example: Simple Green, 409, Greased Lightning)
2. Chamber #2: Rinse water (change rinse water often)
3. Chamber #3: Chamber for dirty water

- Wash no more than 3'x3' area before cleaning your sponge or rag.

b. **Floors:** Should be detergent washed with water and cleaner.

- Use the 3-chamber method to wash:

1. Chamber #1: Water & detergent (example: Simple Green, 409, Greased Lightning)
2. Chamber #2: Rinse water (change rinse water often)
3. Chamber #3: Chamber for dirty water

- Wash no more than 4'x4' area before cleaning your mop.

3. **Vacuum Again:** You will need to use a HEPA filtered vacuum. HEPA vacuum the entire area, start high and work your way down to the floor. Include window sills and wells. Vacuum the floor last.

4. **Isolate the Area:** Once you have finished cleaning make sure to close all windows and doors to prevent recontamination.

